



Monoxor[®] II

Carbon Monoxide Analyzer

Bacharach's Monoxor II CO Analyzer is a hand-held instrument designed to locate CO in ambient air as well as stack gases. The continuous sampling instrument quickly and accurately measures levels of CO between 0 and 2,000 ppm. The Monoxor II has a stainless steel probe with four feet of tubing to sample CO found in flue gases of residential furnaces, combustion appliances, commercial and industrial boilers.

With the addition of the Breath Analysis Module (BAM) to the Monoxor II, it becomes a powerful tool in determining the presence and level of CO in the bloodstream. The Monoxor II is also available in a high range version (0-85,000 ppm) for vehicle emissions testing and forklift tuning.

Features

- Quickly measures and displays low levels of CO 0-2,000 ppm
- Measures in increments of 1 ppm
- Multi-purpose strap for easy holding
- Probe and hose assembly for flue gas testing
- Highly visible digital display with backlight

Applications

- CO safety checks on combustion stack gas and ambient air levels
- Analyzing indoor air quality and safety
- Furnace and boiler servicing or replacement
- BAM verifies CO exposure



ORDERING INFORMATION

PART NO.	DESCRIPTION
19-8004	Monoxor II CO Analyzer with case
19-8014	Monoxor II with CO Breath Analyzer Module
19-8011	CO Breath Analysis Module kit
19-8015	Monoxor II High Range (0-85,000 ppm)
24-0519	CO sensor
19-3076	Probe and hose assembly
19-0441	Adjustment screwdriver
11-0121	Filtering material (for water trap)
24-7059	Calibration kit (without CO gas)
24-0492	CO Gas Cylinder, 500 ppm (for use with 24-7059)
51-1994	CO Gas Cylinder, 100 ppm (for use with 24-7059)
24-0891	Bent Probe Adapter
19-8012	BAM Replenishment kit, 30 mouthpieces, 30 balloons and 10 filter disks.
19-0435	BAM Mouthpiece & balloon, 1 each per pkg.
19-0431	Filter disks
19-0444	RFI Protective Pouch
19-8022	Probe & hose repair kit