

Comparison Test Pump



The **Comparison Test Pump** is a hydraulic hand operated unit that provides a quick and cost effective means of comparing readings between, for example, a test gauge and a standard pressure gauge, pressure switch, etc.

Specification

Range: 0-700bar / 10,000 psi
Case: Cast aluminium
Priming: Direct via ram screw.
Weight: 5 kg.
Dimensions: 340 x 380 x 150mm.

Standard accessories

All testers are supplied with:
 Set of adaptors consisting of 1/8", 1/4", 3/8", 1/2" BSP plus right angled adaptors to take above.
Note:- NPT adaptors available on request - Part No: DW6127

Suitable Liquid:

Alcohol, Vegetable/Mineral oil, Methylated Spirits, Hydraulic fluid, Paraffin, Water.



ORDER CODE No.	DESCRIPTION
4740	Comparison Pump

'Skydrol' version available/ (4740-S)

Oxytester



The **Oxytester** is an efficient means of transmitting pressure from one liquid to another via a flexible diaphragm suitable for use with oxygen clean applications. Connected directly to the test station of an oil operated deadweight or comparison pump the oxytester provides a barrier between the oil and the instrument being calibrated.

Specification

Range: 0-550 bar / 8000 psi
Body: Aluminium Bronze.
Diaphragm: PTFE.
Connection: Inlet: 3/8" BSP Male .
 Outlet: 3/8" BSP Female .
Dimensions: 173 x 100 x 175mm.
Weight: 3.5 kg

Suitable Liquids:

Alcohol, Vegetable / Mineral oil, Methylated Spirits, Hydraulic fluid, Paraffin, Water.

'Skydrol' version available (2740-B).

ORDER CODE No.	DESCRIPTION
2740	Oxytester

www.si-pressure.com

Tel: 0121 784 6855 (UK) Tel: +44 121 784 6855 (Int)
 Fax: 0121 784 4795 (UK) Fax: +44 121 784 4795 (Int)

