

Configuration Software



FEATURES

- Full integrated software for W3600, W3200 panel meters and series WMTX transmitters
- Input, output, display and functions configuration
- Intuitive and easy to use interface
- Data entry validation
- Editing, printing and saving of the configuration
- Input and output signal monitoring in numerical or analog form
- Windows® 3.1, 95/98 or NT freeware application: requires I-S-C adapter to connect the PC to the instruments

Windows is a registered trademark of the Microsoft Corporation.

GENERAL DESCRIPTION:

The configuration software W Link requires a personal computer with 486 or better, a serial RS232 port and Windows® 3.1, 95/98 or NT4.0. The communication cable MCOMM with isolated adapter does not require any power supply. The software lets you prepare configurations, modify, save them as file, print them; then you can transfer them to any transmitter. W Link is a multi-function software able to configure all W3200, W3600 panel meters as well as WMTX transmitters. ATCWestcon will provide this software free of charge to all customers and you can also download the last updated version at www.ATCWestcon.com

SIGNAL MONITORING

- Ability to monitor input and output signals in numerical or analog form
- Ability to see the values (raw or in engineering units) before or after linearization

I-S-C (INTERFACE SERIAL CABLE)

- RJ-11 connector (standard 6 pin telephone connector)
- DB 9 Serial connector
- Isolator board
- Adapter for 3200's front panel access
- 8 foot total length

